



Medicine Herbal Medicine Crushing Machine



The machine consists of feeder, grading wheel, pulverizing blades, gears, pulverizing motor, discharging gate, fans, raw material collection box and dust collection box, etc. Any raw material, being fed into the grinding chamber through the upper feeder is pulverized by high-speed running blades. The fans will lead pulverized material from grinding chamber to discharge gate via negative pressure and the pulverized material will be left to be pulverized. The dust from grinding is filtered and recycled via the cloth bag or filtered by the dust absorption box.

Technical Parameters

Model	200	300	400
Capacity(kg/h)	10-150	20-300	50-500
Size of input granules(mm)	≤10	≤12	≤15
Fineness of products(mesh)	20-250	20-250	20-250
Grinding power(kw/h)	5.5	7.5	11
Dust absorption power(kw/h)	1.5	2.2	3
Weight(kg)	320	550	750
Overall size L*W*H(mm)	1350*920*1800	1400*1050*2050	1600*1150*2100