

DPP-260A/E Pharmaceutical Capsule CNC Blister Packing Machine



The biggest characteristic of this equipment is using mold positioning design, convenient for customers to replace the mold, reduce debugging time and material cost, the key parts are made of high quality stainless steel and high-grade Aluminum Alloy materials by machining center (CNC), mirror line cutting and other high precision CNC equipment into one processing type, retain the original texture finishing, highlight the noble quality.

The transparent protective cover of fine workmanship arc to ensure the safety and the drawing processing of stainless steel cover operation add unlimited style for the overall design, the mechanical products can also bloom artistic charm, the whole process of the details of the pursuit of perfection concept throughout the design and production.

Feature

1. The whole machine can be divided into packaging to enter the 2.2 meter elevator and split purification workshop.
2. The key components are all made of high quality stainless steel and high-grade aluminum alloy material.
3. Novel mold positioning device, It is very convenient to replace the mold with the positioning mold and the whole guide rail ,to meet the general requirements of quick mold change.
4. For an independent station make indentation and batch number separation, so as to ensure the clarity of the indentation and printing (indentation and batch number can also be in a position).

5. The transmission of the machine is isolated from the work area to prevent pollution and facilitate cleaning.
6. The material feeding is controlled by the precision servo motor, the synchronous precision and the length of the stroke are randomly set by the man-machine interface.
7. The heat sealing cylinder is placed under the heat sealing station to reduce machine center, enhance the running stability of the equipment. For the region and the transmission mechanism is completely isolated to prevent pollution, easy to clean up.
8. Aluminum / plastic (hot forming) and aluminum / aluminum (cold forming) General Institutions: Aluminum/Aluminum packing just change the mold and corresponding feeder is OK.

Technical Data

PVC max diameter	φ300mm
PTP max diameter	φ250mm
Tropical foil max diameter	φ300mm
Waste collection max diameter	φ400mm
Cold forming(ALU ALU)forming stretch area and depth	250mm×100mm×12mm (Beyond the area and the depth is determined according to the customer requirements)
PVC forming area and depth	250mm×100mm×13mm (Beyond the area and the depth is determined according to the customer requirements)
Servo motor control stepless adjustable stroke	10mm~120mm (Beyond above stroke, according to the customer requirements)